


digit which begin with "1,2,3,.....9". Each of them can be 1-13 digits, whatever master code or user code .

2.2 Change the master code:

Input the original master code "0123" and "ON", then input the new code and "S" during the red light indicator is on. e.g. Input "0123" "ON" "0181818" "S", then the new master code becomes "0181818".


2.3 Reset the master code:

If the master code has forgot, press reset key , it'll come back to the original code "0123".

Set up the user code:

Input the master code and "ON", then input the first group of new code and "S", it'll be set up a new user code; if then input second group of new code and "S", it'll be set up two new user codes; as this way, totally you can set up 9 groups of user codes.
e.g. Input "0123" "ON" "1234" "S" "2255" "S", it'll be set up two groups of new code: "1234" and "2255".

2.5 Change the user code:


Input the current user code and "ON", during the red light indicator  is on, input a new user code and "S", then the user code becomes the new code.

e.g. Input the current user code "1234" "ON" "1555" "S", now the user code becomes: "1555".

2.6 Cancel the user code:

Input the master code and "ON", and input "0000" "S", then all the user codes have been cancelled.

3. How to Unlock

Input the user code or master code, then press "ON", the green light indicator  will on, turn the handle, the lock will be opened.

4. Protecting the code:

During the unlocking, if there's somebody besides you, you can input a wrong code intentionally and press "S", then continuously input the correct code and press "ON", the lock will be opened, but the besides person cannot get the correct code.

Notes

1. Each time to input code and unlock, needs to till the indicators off.
2. The master code is the original code, it should be remembered anytime.
3. Please read the User Instruction carefully before you install and use the lock.

USE